

WATCH THE VIDEO cudaoptics.com/settings



Watch our easy-to-follow guide and learn how to check your battery, adjust Intensity Offset, and enable/disable Enhanced Shutoff and audio.

Rev B

NEED HELP?

- 📞 (321) 422-3991
- ✉ support@cudaoptics.com
- 🌐 cudaoptics.com



Cuda by Zvetco · 489 S.R. 436, Suite 109 · Casselberry, Florida 32707

QUICK START GUIDE

CUDA RX-795 REFLEX SIGHT



STEP 1. INSTALL BATTERY

- A. Insert large flathead end of supplied multi-tool into slot on battery cover and turn counter-clockwise.
- B. Place CR1632 battery into tray with positive (+) side up.
- C. Replace cover and screw clockwise to tighten.



Do not overtighten the battery cover or misalign its threads as this may damage your sight.



STEP 2. MOUNT

Your Cuda sight can be mounted to both handguns and long guns using the supplied picatinny rail mount or by purchasing a mounting plate and screws from your firearm manufacturer or 3rd-party vendor. (See Mounting Guide link on next page.)

- A. Place sight flush on mount and align holes in mount with holes in sight.
- B. Attach sight to mount using appropriate mounting screws.

Always defer to your plate manufacturer's specifications when selecting appropriate mounting screws.



Removable thread-locking fluid (not included) may help with mounting screws that become loose after repeated use.

STEP 3. SHOOT!

You're now ready to shoot! Pick up your firearm and your sight will instantly turn ON. To turn it OFF, just set it down or holster it.

For more information, see your Cuda sight's User Manual.

HOW WILL THIS FIT MY GUN?

Search for your specific firearm in our **Mounting Guide** at CudaOptics.com.

